

Technical Information Bulletin

2

In-use testing of Therminol heat transfer fluids

When Eastman Therminol® heat transfer fluids are used within suggested temperature limits, they should provide years of service.

To help keep that long-lasting performance optimal, Eastman provides a heat transfer system fluid testing service. This service helps detect system malfunction, fluid contamination, and moisture and thermal degradation as well as other areas that impact system performance.

Details of the testing service—how samples should be submitted for testing and guidelines for interpretation of analytical results—are outlined in this publication.

What is the fluid testing program?

Testing begins when a fluid sample from an operating heat transfer system is submitted for analysis. Specific analyses performed depend on the information provided to sales or technical service representatives. Most samples require only a routine analysis. At times, special analyses are performed to help determine the cause of system operational problems. Systems can be tested for total acid number, moisture, insoluble material, viscosity, flash point, and low- and high-boiling components.

Once analysis is complete, a written report is provided with suggestions to help prolong fluid life or improve system performance. General background experience for in-use fluid is the basis used for comparing individual sample results with normal use limits, thus indicating areas for potential corrective action. Maximum limits where corrective action should be taken to prevent further system problems are also suggested.

How often should system samples be analyzed?

A sample should be taken on new systems, on those that have recently been cleaned, and on those that have had a different fluid added. In addition, a sample should be taken at least annually on systems that continually operate at maximum temperature limits. Analysis at least once every three years usually is adequate on systems that operate at least 50°F (28°C) below the maximum limit. When there is a problem, a fluid analysis at that time may indicate the extent of the problem and the urgency necessary for corrective action.

How do I initiate an analysis?

Sample analysis is initiated by

- **Visiting our website**, www.therminol.com, and filling out a Contact Us Form found under the Contact Us tab
- **Calling us**. In North America, you can reach us at 1-800-433-6997. Your local sales and technical specialists for all world regions can also be found on www.therminol.com under the Contact Us tab.

How do I take a sample?

1. A free sample kit, obtained upon analysis request, should be used. The kit contains an aluminum sample bottle, detailed instruction sheet, fluid sample information form, and a preaddressed mailing label.
2. For analysis, 1 pint (0.5 liter) of fluid is required. Withdraw fluid from a circulating line in accordance with instructions provided by the system manufacturer. Cool the sample to 200°F (93°C) or less and place in a clean, metal container. Label the container with your company name, address, specific fluid name, system name (if there are multiple systems at your location), and sample date. Place the sealed container in the addressed box for shipment to Eastman.
3. Observe safe procedures for handling high-temperature fluid during sampling, and ship the sample according to all current local, state, and federal laws and regulations. Fluids with flash points at or below 141°F (60.5°C) must comply with more stringent shipping requirements per DOT 173.121.

Where do I send the sample?

Send by prepaid freight/postage to the designated Eastman testing lab in your region. Eastman has testing labs in North America, South America, Europe, and Asia Pacific.

In the Americas
Eastman Chemical Company Attn: Chief Chemist 702 Clydesdale Avenue Anniston, Alabama 36201 United States
In Europe, Africa, Middle East, and CIS
Eastman Chemical Company Attn: Chief Chemist, QA Laboratory Corporation Road Newport United Kingdom NP19 4XF
In Brazil
Eastman Chemical Company Laboratório Therminol Avenida Papa João XXIII, 4502 CEP: 09370-904—Mauá—SP Brasil
In Asia Pacific
Eastman Chemical Singapore Ltd. Pte Attn: Chief Chemist 50 Sakra Avenue Jurong Island, Singapore 627891

How soon can I get an answer?

Normally, within two weeks of sample receipt, a fluid analysis and reporting will be completed with suggestions for corrective action. In an emergency, analysis can be completed within 48 hours.

What do the test results mean?

Our experience in in-use fluid analysis enables us to determine fluid property limits. If all test results fall in the normal range, the fluid is probably in good condition and reported system problems, presumably, are related to system design or operation. If one or more of the properties fall within the warning range, appropriate corrective action usually should be taken to minimize further change in the fluid or the system operation. Values at or beyond the action limits indicate the potential need for more immediate corrective actions or fluid replacement to ensure that acceptable system performance continues. An outline for interpreting test results follows. Although the test results suggest possible problems and corrective actions, customers must make their own determinations for their systems based on their particular circumstances.

Viscosity

Viscosity changes generally indicate contamination, thermal stress, or oxidation degradation. Viscosity is related to molecular weight of fluid components. Generally, lower-molecular-weight components decrease viscosity, and higher-molecular-weight components increase viscosity. Contamination from leaked process streams, incorrect material added to the heat transfer fluid system, and solvents from system cleaning, as well as thermal stressing and oxidation, may be the source of materials that increase or decrease viscosity.

Operational problems may result from either high- or low-viscosity conditions. If viscosity is very high, the circulating system may have difficulty in start-up, resulting in heater burnout. Heat transfer rates may also be reduced. If viscosity is low, low-boiling components will be more volatile and can result in pump cavitation and reduced flow.

To remove low-boiling components, heated fluid should be circulated through the expansion tank with inert gas purge of the vapor space. The vent discharge should be routed to a safe location for collection and disposal.

High viscosity generally requires that the fluid be removed and replaced. Sometimes, however, correction can be obtained through dilution with new fluid. The cause of viscosity changes should be determined no matter what action is taken. Equipment malfunction or use of fluid beyond recommended temperature limits can result in thermal or oxidative degradation. The system can be corrected mechanically, or a fluid with a higher thermal stability can be used.

Total acid number

High acid numbers generally indicate possible contamination from material added to the system inadvertently or leaked from the process side. High acid numbers may also indicate severe fluid oxidation if the system is not protected with inert gas in the expansion tank vapor space. Although not routinely reported, pH values can be useful in fluid and system condition assessment.

If the acid condition becomes excessive, the system can corrode and fail. Corrosive products form sludge and deposits that decrease heat transfer rates.

A contamination or oxidation condition of this nature usually should be corrected by removing the material for disposal and replacement with new fluid.

Moisture

Moisture generally indicates that there is either a system leak on the process side or wet fluid has been added to the system. New systems, or systems cleaned using aqueous solutions, can contain residual water. Water can also infiltrate through the open vents of expansion or storage tanks. Corrosion, high system pressures, pump cavitation, and vapor lock are possible problems caused by moisture. If hot fluid contacts a water pocket, there is potential for steam to develop, which can cause fluid from the system to erupt and its components to fail.

Corrective actions include careful and gradual start-up of a potentially wet system with circulation through all parts until the boiling point of water has been exceeded. Heated fluid is circulated through the expansion tank where vapor space is slowly purged with inert gas to sweep moisture from the system. If a large amount of water contamination is present, it may be necessary to remove the fluid for external drying. Leaks from the process side should be corrected, and new heat transfer fluid should be stored to minimize water entry.

Note: When stored outside, new, sealed drums should be turned on their sides and adequately covered to prevent moisture contamination from the rain.

Acetone insolubles

The presence of acetone insoluble solids generally indicates contamination from dirt, corrosion products, severe oxidation, or severe thermal stressing.

This condition may cause fouling of heat transfer surfaces, plugging of small-diameter lines, or narrow heat transfer passages as well as wear and plugging of mechanical seals and valves.

If these problems occur, side-stream filtration using glass fiber-wound filters usually can eliminate the source of dirt, corrosion, oxidation, or thermal stress. If solids contamination is extremely high, fluid may need to be removed for external filtration and the system may need to be cleaned. Therminol FF flushing fluid has proven effective in removing fouling deposits from most synthetic and mineral oil systems. Modest solids content may require successively smaller-rated filter sizes to get the situation under control. A suggested filter rating generally is 10 to 25 microns.

Low- and high-boiling components

Low- and high-boiling materials are measured by gas chromatographic analysis and generally indicate contamination, oxidation, or thermal stressing of fluid.

This condition can cause pump cavitation, a poor circulation rate, and decreased heat transfer rates. Ultimately, it can result in the fouling of heat transfer surfaces and the formation of solid materials.

To correct, remove the source of contamination, correct the abnormal thermal stress, and purge low boilers from the system. Very high levels of low and high boilers may require removal of fluid for reclamation or disposal.

Special tests

There are certain times when special testing is needed. This testing includes solids and component analysis to help identify a source of contamination, a cause of degradation, or an operational problem. Compatibility of one fluid with other fluids, components, or materials of construction helps to assure trouble-free performance.

Can I test the fluid in my lab?

Test procedures are based on standard ASTM methods. Many labs have the capability to do these tests. Details for running specific tests are available and may be requested.

Specific analytical testing may not be needed to determine the general condition of in-use fluid. A simple visual inspection can show if more detailed analysis is needed. Fluid from a well-maintained heat transfer system will usually be dark in color with viscosity similar to new fluid. Presence of moisture will result in cloudiness or separate fluid layers. High solids will usually appear as sediment at the bottom of a container.

Summary of in-use Therminol fluid test result interpretation

Test	Possible cause	Possible effects
Viscosity changes	Contamination, thermal degradation, fluid oxidation	Poor heat transfer rate, deposits, high vapor pressure, pump cavitation
Total acid number changes	Severe oxidation, contamination with acid or base	System corrosion, deposits
Moisture increase	System leaks, residual in new or cleaned unit, unprotected vent or storage	Corrosion, excess system pressure, pump cavitation
Acetone insoluble solids increase	Contamination, dirt, corrosion, oxidation, thermal stress	Poor heat transfer, wear of pump seals, plugging narrow passages
Low- and high-boiler increase	Contamination, thermal stress	Pump cavitation, poor heat transfer, excess system pressure, deposits
Special and appearance testing can be completed as needed for quick determination of fluid condition or resolution of special problems.		

For more information or to find the sales or technical contact nearest you, visit the "Contact us" page on our website:
www.therminol.com.

North America
Solutia Inc.
A subsidiary of Eastman Chemical Company
575 Maryville Centre Drive
St. Louis, MO 63141 U.S.A.
Telephone:
Customer Service, 800-426-2463
Technical Service, 800-433-6997
Fax: Customer Service, (1) 314-674-7433

Latin America
Solutia Brasil Ltda.
A subsidiary of Eastman Chemical Company
Rua Alexandre Dumas, 1711—Birmann 12—
7º Andar 04717-004
São Paulo, SP, Brazil
Telephone:
Brazil, 0800 55 9989
Other Locations, +55 11 3579 1800
Fax: +55 11 3579 1833

Europe/Middle East/Africa
Solutia Europe SPRL/BVBA
A subsidiary of Eastman Chemical Company
Corporate Village—Aramis Building
Leonardo Da Vincilaan 1
1935 Zaventem, Belgium
Telephone: +32 2 746 5000
Fax: +32 2 746 5700

Asia Pacific
**Eastman (Shanghai) Chemical
Commercial Company Ltd.**
Building 3, Yaxin Science & Technology Park
Lane 399 Shengxia Road
Pudong New District
201210, Shanghai, P.R. China
Telephone: +86 21 6120 8700
Fax: +86 21 5027 9229

EASTMAN
The results of insight™

**Eastman Chemical Company
Corporate Headquarters**

P.O. Box 431
Kingsport, TN 37662-5280 U.S.A.

U.S.A. and Canada, 800-EASTMAN (800-327-8626)
Other Locations, +(1) 423-229-2000

www.eastman.com/locations

Although the information and recommendations set forth herein are presented in good faith, Eastman Chemical Company and its subsidiaries make no representations or warranties as to the completeness or accuracy thereof. You must make your own determination of its suitability and completeness for your own use, for the protection of the environment, and for the health and safety of your employees and purchasers of your products. Nothing contained herein is to be construed as a recommendation to use any product, process, equipment, or formulation in conflict with any patent, and we make no representations or warranties, express or implied, that the use thereof will not infringe any patent. NO REPRESENTATIONS OR WARRANTIES, EITHER EXPRESS OR IMPLIED, OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OF ANY OTHER NATURE ARE MADE HEREUNDER WITH RESPECT TO INFORMATION OR THE PRODUCT TO WHICH INFORMATION REFERS AND NOTHING HEREIN WAIVES ANY OF THE SELLER'S CONDITIONS OF SALE.

Safety Data Sheets providing safety precautions that should be observed when handling and storing our products are available online or by request. You should obtain and review available material safety information before handling our products. If any materials mentioned are not our products, appropriate industrial hygiene and other safety precautions recommended by their manufacturers should be observed.

© 2016 Eastman Chemical Company. Eastman brands referenced herein are trademarks of Eastman Chemical Company or one of its subsidiaries. The ® used on Eastman brands denotes registered trademark status in the U.S.; marks may also be registered internationally. Non-Eastman brands referenced herein are trademarks of their respective owners.